

Adjusta-Magic

**E-90
hand control**

OPERATION GUIDE

HEAD UP BUTTON
Press and hold to raise the head section.

HEAD DOWN BUTTON
Press and hold to lower the head section.

FOOT UP BUTTON
Press and hold to raise the foot section.

FOOT DOWN BUTTON
Press and hold to lower the foot section.



SAFETY NOTE:

To prevent unauthorized use of this product, unplug the control cord from the base of the hand control and store in a secure location. To resume operation, simply plug the control cord into the hand control.

IMPORTANT:

Read advisory information in the owners manual carefully before using this product. The potential for electrical shock exists if electrical components are not installed or operated properly.